

Cockpit Electrical Centre Fuse Layout

Clock/Theft Alarm/ Logistics	FC04 5A
HVAC module	FC03 7.5A
Reserved	FC02 free
Reserved	FC01 free

Addtnl Heater Step 1	FC09 40A
Addtnl Heater Step 2	FC08 40A
Addtnl Heater Step 3	FC07 40A
Body Contrl Mod 2	FC06 30A
Body Contrl Mod 1	FC05 40A

Reserved	FC17 Empty
Reserved	FC16 Empty
Onboard Diag. (OBDII)	FC15 10A
Ignitn Swtch/Steering Wheel	FC14 10A
Emergency Call	FC13 Empty
Head Unit	FC12 20A
HVAC Module	FC11 7.5A
Reserved	FC10 Empty

12V Rear Outlet	FC23 15A
USB charging	FC22 5A
12V Front Outlet	FC21 15A
Reserved	FC20 Empty
Reserved	FC19 Empty
Reserved	FC18 Empty