

HVAC Air Flow Settings

Fan Speed	Air Direction	Windshield Vent	Face Vents	Footwell Vents	Rear Vents
Fan speed 1	Face		Yes		Yes
	Face - Footwell		Yes	Yes	
	Footwell			Yes	
	Windscreen - Footwell	Yes		Yes	
	Windscreen	Yes			Yes
Fan Speed 2	Face		Yes		Yes
	Face - Footwell	Yes	Yes	Yes	Yes
	Footwell			Yes	
	Windscreen - Footwell	Yes		Yes	
	Windscreen	Yes			Yes
Fan speed 3	Face	Yes (trace)	Yes		Yes
	Face - Footwell				
	Footwell	Yes (trace)		Yes	Yes (trace)
	Windscreen - Footwell	Yes		Yes	Yes (trace)
	Windscreen	Yes		Yes (trace)	Yes
Fan speed 4	Face	Yes (trace)	Yes		Yes
	Face - Footwell	Yes	Yes	Yes	Yes
	Footwell	Yes (trace)		Yes	Yes (trace)
	Windscreen - Footwell	Yes		Yes	Yes (trace)
	Windscreen	Yes		Yes (trace)	Yes