

## Cub Longreach LE Check List

# Unhitching & Setup

Completed

*Always Remember: Take Your Time, Never Rush and Double Check*



|    |  |  |
|----|--|--|
| 1  | Level camper trailer side to side, ie crossways.   |  |
| 2  | Unhitch safety chains & unplug 7 pin & Anderson plugs.   |  |
| 3  | Apply camper hand brake.   |  |
| 4  | Attach jockey wheel and tighten clamp.   |  |
| 5  | Undo hitch. Pull handle up while winding jockey wheel, until camper comes off the ball.  |  |
| 6  | Drive vehicle off.   |  |
| 7  | Level camper end to end with jockey wheel, then wind jockey wheel down 6 turns.  |  |
| 8  | Wind down rear stabiliser legs till firm on ground.  |  |
| 9  | Fit floor legs if removed.   |  |
| 10 | Wind jockey wheel up 6 turns until level again.  |  |
| 11 | Unlatch rear utility rack and swing aside.   |  |
| 12 | Undo the roof/floor lock down latches, starting at the rear & finishing at the front.  |  |
| 13 | Unwind winch strap and lift roof/floor until STOP mark appears on the strap.   |  |
| 14 | Continue unwinding until opened ensuring that the strap is very loose.   |  |
| 15 | Check vertical gap between floor and rear of camper is ≈ parallel.   |  |
| 16 | Drop floor legs, stabilise floor and securely tighten leg screws.  |  |
| 17 | Walk around and fix tent bungee loops and press studs, to camper body.   |  |
| 18 | Inside the tent, release snap lock clips on rear tent bow and push firmly out. Lock clips. Fit and adjust the 2 support poles to the rear corners of bow.  |  |
| 19 | Undo rear bow locking screws at centre bow. Release snap locks and raise arms to horizontal position and lock screws. Gently push bow out again and lock clips.  |  |
| 20 | Fit and adjust the front tent bow support poles.   |  |
| 21 | Check that the door zips open and close easily.  |  |
| 22 | Plug in LED light strip.   |  |
| 23 | <p>Turn on power at Redvision display in control locker. Switch on all circuits, except rear work light (unless needed):</p> <ul style="list-style-type: none"> <li>• 3 x 12v power: External back, Ext/front locker door, Hot water/int back</li> <li>• Lights</li> <li>• Water Pump/Kitchen</li> <li>• Radio and sub-woofer</li> <li>• Bed Head USB</li> <li>• Fridge (if switched off)</li> </ul>   |  |
| 24 | Turn on water tank valve/s and switch on pump at either control locker or kitchen.   |  |
| 25 | Turn on gas.   |  |
| 26 | Remove cover from hot water system & then switch on at control locker.   |  |
| 27 | Set up annex if attached.  |  |
| 28 | <p>Open Kitchen.</p> <ul style="list-style-type: none"> <li>• Unlock and pull out.</li> <li>• Pull slightly harder on the left handle to ensure 12v power connection. Lock in place.</li> <li>• Drop and adjust stabiliser leg.</li> <li>• Connect water and gas lines and velcro retainer loop.</li> <li>• Turn on kitchen water valves.</li> <li>• Connect drain hose or grey water jerry to sink.</li> <li>• Remove and fit side shelf and stove wind guard.</li> </ul> |  |
| 29 | Attach outside LED light strip.  |  |
| 30 | or   |  |

## Cub Longreach LE Check List

### Packing Up & Hitching

Completed

*Always Remember: Take Your Time, Never Rush and Double Check*



|    |   |                          |
|----|---|--------------------------|
| 1  | Pack up Kitchen. <ul style="list-style-type: none"> <li>• Remove grey water jerry and/or drain hose.</li> <li>• Turn off kitchen water valves and kitchen pump.</li> <li>• Disconnect water and gas hoses. Roll up into storage locker.</li> <li>• Raise and secure stabiliser leg.</li> <li>• Fold up and secure side shelf and stove wind guard under kitchen.</li> <li>• Unlock, close kitchen, lock when closed and lock door.</li> </ul> | <input type="checkbox"/> |
| 2  | Remove outside LED light strip.   | <input type="checkbox"/> |
| 3  | Switch off hot water system at control locker. Replace cover when HWS is cool   | <input type="checkbox"/> |
| 4  | Turn off gas at bottle.   | <input type="checkbox"/> |
| 5  | Turn off water pump in control locker   | <input type="checkbox"/> |
| 6  | Turn off all power circuits (except fridge) at Redvision display in control locker.   | <input type="checkbox"/> |
| 7  | Pack up annex, if attached.   | <input type="checkbox"/> |
| 8  | Sweep floor.  | <input type="checkbox"/> |
| 9  | Turn off stereo and fit rubber cover.   | <input type="checkbox"/> |
| 10 | Lock drawers.   | <input type="checkbox"/> |
| 11 | Switch off lights,unplug LED light strip and any other 12v accessories.   | <input type="checkbox"/> |
| 12 | Remove front and rear tent support poles and place beside bed.  | <input type="checkbox"/> |
| 13 | Move pillows down bed and place tarp over bed.  | <input type="checkbox"/> |
| 14 | Close side windows and zip up doors, leaving one zip open to get out.   | <input type="checkbox"/> |
| 15 | Drop table, place end on bed and secure.  | <input type="checkbox"/> |
| 16 | Undo rear bow locking screws at centre bow. Lower arms and tighten screws.  | <input type="checkbox"/> |
| 17 | Release snap lock clips on rear tent bow, collapse bow and and lock snap clips.   | <input type="checkbox"/> |
| 18 | Move outside, zip door shut.  | <input type="checkbox"/> |
| 19 | Walk around and undo tent bungee loops and press studs.   | <input type="checkbox"/> |
| 20 | Wind up floor/roof using winch. <ul style="list-style-type: none"> <li>• Ensure canvas is pulled away from central junction bow &amp; flat.</li> <li>• If the annex is fitted fold it into the camper when floor is around vertical.</li> <li>• Periodically check that the canvas is pulled inside the camper body.</li> </ul>   | <input type="checkbox"/> |
| 21 | Stop winding when there is a gap of 25-50mm between floor and body. <ul style="list-style-type: none"> <li>• Close the roof/floor lock down latches, starting at the rear &amp; finishing at the front.</li> </ul>  | <input type="checkbox"/> |
| 22 | Drop floor legs or remove and store. Tighten leg screws.  | <input type="checkbox"/> |
| 23 | Wind & fold up the rear stabiliser legs.  | <input type="checkbox"/> |
| 24 | Close and secure rear utility rack.   | <input type="checkbox"/> |
| 25 | Hitch to vehicle. Ensure that hitch handle is at the rear of ball & locked down.  | <input type="checkbox"/> |
| 26 | Release camper hand brake.  | <input type="checkbox"/> |
| 27 | Remove jockey wheel, screw up jockey wheel bracket and secure jockey wheel to storage bracket on camper winch post.   | <input type="checkbox"/> |
| 28 | Cross safety chains and secure to vehicle.  | <input type="checkbox"/> |
| 29 | Connect 7pin electric and Anderson plugs.   | <input type="checkbox"/> |
| 30 | Check operation of camper lights and brakes.  | <input type="checkbox"/> |
| 31 | Check trailer battery is charging from vehicle on Redvision display.  | <input type="checkbox"/> |
| 25 | Check locker doors are closed and locked.   | <input type="checkbox"/> |
| 32 | Stop and check all is OK after driving a few kilometers.  | <input type="checkbox"/> |