

Pre-Delivery Inspection MY24

	Vel	nicle Identi	ficati	on Number (VIN):	Model:
				Date:	Engine number:
		Kilome	eter /	Mileage reading:	Locking wheel nut code:
		rior Trim Insp		:	
	NOK	Corrected			
					nt right chassis rail, windscreen panel plate and driver door close
				nove transport protection. Inspect the vehicle interior	, , , , , , , , , , , , , , , , , , , ,
				ce vehicle protection on vehicle (i.e., wing covers, seat te damage on vehicle silhouette on final page	covers etc.)
				pect wheels for damage, (optional equipment) includi	ng snare wheel
				ure the vehicle is correct as per the sales order, include	
		cle check:	NIA		
		Corrected	_		. 1 . 1
	ш		Ц	Remove the plastic blank and install 5amp mini fuse	
				glovebox or centre cupholder	top left of fuse box. Location FC04 (see fuse sheet) 5amp fuse in
				- ·	ary battery (if fitted (Optional Equipment)), are secure to specification
				All keys switch ignition, start engine	ary bactery (if fitted (Optional Equipment)), are secure to specification
					, tell-tale illumination and Diagnostic Trouble Code (DTC) fault memory
				Interior central locking buttons locks / unlocks all do	-
				Drivers tell-tale cluster illuminates	ors and spire door
					urn signals, reverse light, park light, etc. (Including Optional Equipment))
				Headlight functions, headlight alignment aim and wo	
				Brake light functions	TKING NSTIES (Including Optional Equipment)
				Front / rear wipers and washers activate, correctly fit	ted / aligned and clear screens correctly
				All interior lighting functions activate correctly (i.e., ir	
				Rear view mirror function and wing mirrors, (Optional	
					reen, centre console buttons with rotational wheel, preview channel fo
_	_	_	_	satellite radio etc.)	
				Bluetooth connection. Connect telephone, delete mo	bbile phones from system after checking connection
				Set date and time / reset average mileage / (Optional	Equipment) check compass operation
				Seat belt operation, rachet, locking and release of th	e buckle
				Steering column adjustment to end stops in all direc	tions
				Steering wheel switches	
				Horn functions (High / Low tone) and Toot button	
				Handbrake function and travel, adjust if necessary	
				Interior grab handles secure and function correctly	
				Sun visor and mirror operation	
					s (Insert readable source into USB A and C ports (Optional Equipment)
				Front (Optional Equipment) and rear seat operation in	all directions, including head restraints and folder seats
				(Optional Equipment) Seat heating operation	
				(Optional Equipment) Safari roof operation, panels op	
				Correct operation of all windows at each door and fr	
			Ц	Glovebox and (Optional Equipment) centre armrest o	peration, locking / unlocking of the centre console
Toch	iciana	Notos			
reciiii	iicialis	Notes:			
•••••					
••••					
			• • • • •	• • • • • • • • • • • • • • • • • • • •	••••••










				Activation of hazard light (Optional Equipment) PDC sensor operation, and Rear-View camera, ensuring objects are correctly identified
				Heating and AC system operation. Including fan operation, vents and temperature control
				Activation of all interior switches ensuring full functionality Luggage compartment (Loading floor, side flaps, lashing eyelet, blind etc.) (Optional Equipment)
				Complete full INEOS tool kit, including jack
				Compliant labels are fitted (i.e., airbag label on passengers' side, VIN label, towing weights etc.) (Country specific) Enclose / provide regional INEOS / dedicated breakdown assistance information
re-del	livery i	nspection with	ı the v	vehicle Tester:
		Corrected	NA	
				Perform vehicle test, clear DTC / fault code memory NOTE: Check bulletins for known topics. Investigate repeated stored DTC / fault codes without bulletins
				Complete routine, DME / DDE – Remove Transport Mode
				(Country Specific) Ensure eCall is enabled (ECU) and active (ECU SIM). See instructions in Repairer Networking Drive . Follow eCall Grade-X special routine (check ECU enabled, emergency number correct and 'ON') and Vodafone IoT portal activation.
				NOTE : Do NOT press the SOS button until the ECU is enabled, and the SIM is activated NOTE : Raise a technical ticket in the INEOS portal to request activation of the E-CALL SIM card if not active Check battery State of Charge (SOC) in the vehicle infotainment unit (system, vehicle functions, vehicle information, batter
				Charge the vehicle battery until the SOC is at least 85% NOTE: Place vehicle battery on charge with recommended battery charger
				Check the service interval is correct. Set the correct service interval to customer requirements (Normal use / Arduous use Clear fault code memory and print the Diagnosis Session Report
			_	
itn tn	e venic	ie on the grou	ına, o	utside the vehicle check:
OK	NOK	Corrected	NA	
				Remote central locking locks / unlocks all doors, split rear doors and fuel filler with all keys
_	_	_	_	NOTE: Ensure all doors and bonnet are closed, as the horn will sound
				All required keys are present for INEOS accessories (Exterior and Interior (i.e., spare wheel storage, centre
			П	console lid etc.))
				Central locking of driver's door with mechanical key
_				All doors open from exterior and interior handles, including child lock switch of rear door locks
				Door check straps, including split doors, function correctly and hold
			_	Fuel filler flap and fuel filler cap (including AdBlue cap) functions correctly (Ontional Equipment) Activation and function of front and rear winch
				(Optional Equipment) Activation and function of front and rear winch
				(Optional Equipment) Towbar light function with trailer boards
				Registration plate mountings correct front and/or rear
Ш				Release bonnet, check function of safety catch and bonnet stay
				NOTE: Pull twice to fully release the bonnet) Remove engine cover, inspect engine compartment cleanliness
				Engine oil level is correct.
				NOTE: See workshop manual for correct engine oil specification and level
				Both coolant levels, top up, if necessary, with correct coolant / water concentration
_		_		NOTE : See workshop manual for specification. Ensure the correct cap is fitted on each expansion bottle Brake
				Fluid level, top up to maximum with approved DOT4 brake fluid
				Screen washer fluid level, top up, if necessary, with water
echr	nician	s Notes:		
		• • • • • • • • • • • • • • • • • • • •	• • • • • •	
••••	• • • • • •	•••••	• • • • • •	
• • • •	• • • • • •	• • • • • • • • • • • • • • • • • • • •	• • • • • •	














Check for current technical recalls & campaigns, implement if necessary (write NA & date if none-current)

Campaign or Recall Reference Number:	all completed	Date:
Campaign or Recall Reference Number:	all completed	Date:
Campaign or Recall Reference Number:	all completed	Date:
Campaign or Recall Reference Number:	all completed	Date:
Campaign or Recall Reference Number:	all completed	Date:

Vehicle damage reporting

Body Damage	Abbreviation
Scratch	S
Chip	С
Dent	D
Bent	В
Loose	L
Missing	M



I guarantee that the actions specified in this document were performed conscientiously and completely

Technicians Signature	Service Managers Signature
nnician ID number:	
	nnician ID number:

Technicians Notes:



